

TEL-A-TENSION Model Series 4C3000

Threading Instructions

1. Open "pre-tension disk" by pressing against the head of the screw as seen in view "B-B".
2. Guide the wire from the supply spool between the felt disks, then release the pressure to capture the wire between the disks.
3. Thread the wire around the large "tension wheel" in a counter clock-wise direction, approximately 1-1/2 turns, placing it between the outside of the wheel and the o-ring. (As Pictured)
4. Bring the wire away from the tension wheel and under the "brake control wheel" up and over the "indicator wheel" then down through the backside of the "brake control wheel", finally exiting over the top of the "take-off wheel".

